



### 跳线说明

**FLASHBOOT:** 短接后从FLASH启动，悬空从9200片内启动

**AT49-BOOT-28F:** 短接1-2从AT49BV启动；短接2-3从28F启动

**JTAG-ICE:** 短接2-3使能JTAG

Title		
Size	Number	Revision
A4		
Date:	2007-3-26	Sheet of
File:	M:\PCB\...\9200核心板接口_Rev1.0.SCHDOC	
Drawn By:		